


SlouchBuster

Information Page


Note: A full Instruction Manual is supplied with each SlouchBuster. The information below is provided solely as a guide.



1. Place the *SlouchBuster* around your lower back. The buckles must be positioned on the **top strap (Figure 1)**.




2. Making sure the straps are untwisted, place the loops over the knees.




3. Locate the straps just below the knee and engage the slideable buckles between the knees. (**Figure 2**)

4. Tighten the straps by leaning forward and pulling at the same time. (**Figure 3**).




5. Too tight? Simply loosen by lifting the front edge of each adjustment buckle. (**Figure 4**).

6. Detach the lower edge of the carry handles from the hook & loop tabs on each side and fasten them around your waist (**Figure 5**). Now when you get up, the *SlouchBuster* will stay positioned around your waist.




WARNING: DO NOT USE FOR DRIVING!
For driving, inquire about our LumbarJack

7. To take the *SlouchBuster* off, first disengage the knee buckle (**Figure 2**) by pushing the button and pulling it apart, then take the straps off your knees.



8. To re-pack your *SlouchBuster*, first zip two sides to make a pouch. Reattach the belt/carry handles on the hook & loop tabs. Finally, stuff the straps and buckles together into the pouch and zip up the last side. (**Figure 6**).




9. You can use your *SlouchBuster* in a combination of different sitting positions: On any chair, stool, bench, stadium or airline seat (**Figure 7**); crosslegged on the ground (**Figure 8**); or with your legs uncrossed and knees up (**Figure 9**). Note: You don't need to clip the knees together when sitting crosslegged.



Care Instructions: Hand-wash warm and line dry. Heat may damage foam.

One Year Limited Warranty: These products are guaranteed to be free of defects in material and workmanship for a period of one year of normal use. If you experience any problems during this period, please contact Nada-Chair at the numbers below and we will replace or repair the product at our discretion. Warranty does not cover misuse or damage done by intentional or accidental means. Nada-Chair cannot assume any responsibility, special, indirect, or consequential damages, or contingent liability for use of this product in a manner not expressly intended by the manufacturer.



Patents: US #4773106, #5001791, #5083554, #5235714, UK #2233211, NZ #232126, AUS #632084, ROC #54187, PRC #8920904.3x, EP #0421045B1, DE #69013111T2, MEX #165130, KOR #96761, other patents pending.

Nada-Chair & SlouchBuster are registered trademarks of Nada-Concepts, Inc.
Copyright © 2001, Nada-Concepts, Inc. All rights reserved.